Datalogic PM8300 – RS-232 configuration

Scan the following barcodes:

Restore PowerScan® M8300 Default

Enter Configuration

Set Radio Address

Scan the bar code on the base representing a number between 0001 and 1999.

Exit and Save Configuration

Bind

(The green light on the drive will flash)

Place the player on its base for about 10 seconds.

(The reader light will go out and the base will beeper)

Continue scanning the following barcodes:

COMMUNICATION RS-232

Standard

Enter Configuration

ChronoMEDIC

19200 baud

timeout control in reception from Host

0

0

RADIO PROTOCOL TIMEOUT

radio protocol timeout

0

4

RADIO RX TIMEOUT

always on

POWER-OFF TIMEOUT

power-off timeout

0

1

DISPLAY-OFF TIMEOUT

timeout

9

9

SCREEN REFRESH

Disable

Exit and Save Configuration

Test using HyperTerminal (or a program of the same type) with the parameters "19200-8-1-None"

In ChronoMEDIC, install the Standard drive.

ChronoMEDIC