

Datalogic PM8300 - USB configuration

1. Run Powerscan M8300 USB-COM_Driver Driver.com (Extract Files. Note location for step 6).
2. Plug the USB cable into the Powerscan base and into the base and electrical socket.
3. Scan the bar code of "Restore PowerScan M8300 Default", the bar code of the base and put the scanner on the base



4. Plug the USB cable into the PC.
5. If a hardware installation window opens, you are already in USB-COM mode, otherwise, scan the USB-COM bar code on page 11 of the basic booklet.



6. In the hardware installation window, point to the directory where the files were extracted
7. Continue installation normally
8. In ChronoMEDIC, install the drive as a "Standard" drive, 9600-8-N-1